



PREMIUM AFTERMARKET WIND DEFLECTORS

Mercedes-Benz W111 1961-1971 Wind Deflector

Product No.: 23.01.01.01B (BLACK)

Product No.: 23.01.01.03B (BEIGE)

What's in the box

1 x wind deflector

1 x installation manual

2 x wind deflector brackets (left & right).



INSTALLATION INSTRUCTIONS





STEP 1

Open the top and fold the seats forward. Remove the cover of the rear side panel by loosening all phillips screws.





STEP 2

Attach both wind deflector brackets (left & right) and place back the side panel cover.



STEP 3

Hold the wind deflector in the car and hang the rear brackets over the edge of the side panel.





PREMIUM AFTERMARKET WIND DEFLECTORS



INSTALLATION INSTRUCTIONS

STEP 4

Click the wind deflector pins into the installed plugs.



STEP 5

Go out for a test drive and enjoy your wind deflector!

