



PREMIUM AFTERMARKET WIND DEFLECTORS



INSTALLATION INSTRUCTIONS

Triumph Stag Wind Deflector 1970-1978

Product No.: 35.03.01.01

What's in the box

1 x wind deflector

1 x installation manual





STEP 1

Open the top and fold the seats forward then open the soft top storage compartment.



STEP 2

Place the wind deflector in the car. The brackets in the front and rear go over the edge of the soft-top storage compartment.





PREMIUM AFTERMARKET WIND DEFLECTORS

INSTALLATION INSTRUCTIONS

STEP 3

Close the soft top storage compartment cover.



STEP 5

Go out for a test drive and enjoy your wind deflector!

