



PREMIUM AFTERMARKET WIND DEFLECTORS

Nissan 370Z Roadster wind deflector fitting instructions

Product No: 26.02.01.01



What is in the box

1 x Wind deflector

1 x Installation manual

STEP 1

Open the top.

STEP 2

Slide this wind deflector in the slots that are located in the center of the roll bar covers.

