

Instruction manual

Luggage rack Midget



1. Put a blanket on the boot lid so you can't scratch it.
2. Bolt the brackets to the luggage rack but not completely just enough to hold them. But the protective strips that are supplied with the boot rack on the places where the brackets touch the boot lid in order to protect the paintwork.
3. Hook the brackets on the edge of the boot lid.
4. Fasten all bolts.
5. Test if the luggage rack is installed correctly.
6. Technical information:  
Max. Load capacity: 15,00 kg  
Weight: 4,5 kg